# Installation PC USB Driver

(only for the PC with windows system, no need if your system is MAC.)

1. Double click the file of

   XMOS_EVAL_KITS_DriverSetup_v3.34.0.exe

2. Click "Next"

3. Make sure the version is v3.34.0 and click "Next"

4. Choose the path and click "Install"

5. After the installation, click "Next"

6. Then click "Finish"